

Western 1-Kote

Western 1-Kote Component Assembly

System Details

Typical Installation

Systems must comply with local building codes and applicable standards. Details shown in this document are for guidance and informational purposes only. Western Blended Products disclaims any liability regarding the use of these drawings and document for any project purpose. The designer of the project determines the functionality equivalency of these details and how these are suited for the project. Installation details may change with time. Please contact Western Blended Products for more information.

Termination at Window With Integral Flange Approved Sheating Weather resistant barrier over flashing membrane Foam Insulation Woven Wire or Metal Lath. Western 1-Kote Finish Coat - Continuos over foam popout. Flashing membrane Optional foam shape laminated to Western 1-Kote Casing Optional Backer Rod and Sealant Typical vinyl / metal window with integral stop flange **Design of integral flange stop will vary by window manufacturer.

April 2018

System Detail

Visit us on the web: westernblended.com



